

SBR Hammerhead Spring 500 Straight A/S



Manufacturer: Greggersen

Product 703510

Number:

Description

Manual cutting torch (SBR) 500mm A/S,
Injector torch for flame cutting applications
with acetylene (C₂H₂),
WITHOUT heating and cutting nozzle,
with two handwheels for targeted mixed gas regulation and
spring lever for fast cutting oxygen control.

Medium: Acetylene / Oxygen

Total length: approx. 500mm

Torch head: Hammer head

Handle: straight with handle shells

Cutting O₂ valve: spring lever

Housing: Brass